



## How To Install a Carbide Bur



Dremel shown with collet nut tightened down completely



remove the collet nut from the Dremel



as you can see from this picture the collet was stuck inside of the collet nut



gently remove the collet from the collet nut



replace the collet into the Dremel (you can test the bur or even insert the bur at this point if you prefer)



replace the collet nut, but do not tighten completely



leave collet opening large enough to insert carbide bur



insert carbide bur and tighten down the collet nut. (Note: the first few times you insert your carbide bur, it may be snug. This is normal)